
Citrus Circuits Machine Shop Reference Information

Recommended RPM for Drilling Operations



All holes 1/2" or greater should be drilled in 1/8" increments, starting with 3/8"



Run center drill at speed according to the largest diameter of the center drill



Countersink bits are run at 300 RPM max



Counterbore bits are run at 200 RPM max

Reamer bits are run at ~100 RPM



